How to Write Fast Numerical Code

Spring 2013

Lecture: Roofline model

Instructor: Markus Püschel

TA: Georg Ofenbeck & Daniele Spampinato

ETH

Eidgenössische Technische Hochschule Zürich Swiss Federal Institute of Technology Zurich

Operational Intensity Again

Definition: Given a program P, assume cold (empty) cache

Operational intensity:
$$I(n) = \frac{W(n)}{Q(n)}$$
 #flops (input size n)

#bytes transferred cache \leftrightarrow memory (for input size n)

Examples: Determine asymptotic bounds on I(n)

■ Vector sum: y = x + y O(1)

■ Matrix-vector product: y = Ax O(1)

■ Fast Fourier transform O(log(n))

Matrix-matrix product: C = AB + C O(n)

Example MVM: y = Ax + y

- Number of flops?
- Number of compulsory misses (cold cache)?
- Upper bound on the operational intensity?

3

Compute/Memory Bound


- A function/piece of code is:
 - Compute bound if it has high operational intensity
 - Memory bound if it has low operational intensity
- The roofline model makes this more precise
- Blackboard


Roofline Measurements


- Tool developed in our group (G. Ofenbeck, R. Steinmann, V. Caparros-Cabezas, D. Spampinato)
- You can use it in your project
- Example plots follow
- Get bounds on I:


daxpy: y = αx+y
 dgemv: y = Ax + y
 dgemm: C = AB + C

FFT









Summary

- Roofline plots distinguish between memory and compute bound
- Can be used on paper
- Measurements difficult (performance counters) but doable
- Interesting insights: use in your project!